



# Vinyl Stair Tread, Riser, & Stringer

## INSTALLATION

*This document is intended for professional use to provide minimum requirements for substrate preparation, adhesive application, and special installation requirements for a successful installation of these products, each unique application may require additional or further steps to ensure complete satisfaction. We rely on the expertise and professionals that are installing the products to adjust based on site conditions. Refer to the product website to confirm that you have the most current revision of this document as the requirements contained within are essential to maintaining the full system warranty for the product installed. Documentation available at time of installation will be referenced regarding warranty.*

|                                                                                |   |
|--------------------------------------------------------------------------------|---|
| <b>RECOMMENDED ADHESIVES</b>                                                   | 1 |
| <b>INSTALLATION CONSIDERATIONS</b>                                             | 2 |
| ABRASIVE and/or SMOOTH / RIBBED RUBBER INSERTS                                 | 2 |
| BUTTING TREADS and/or PATTERN ALIGNMENT                                        | 2 |
| <b>STORAGE, HANDLING, INSTALLATION, SERVICE, &amp; ACCLIMATION ENVIRONMENT</b> | 2 |
| <b>SUBSTRATE PREPARATION</b>                                                   | 3 |
| NON-APPROVED SUBSTRATES                                                        | 3 |
| CONCRETE SUBSTRATES                                                            | 4 |
| WOOD SUBSTRATES                                                                | 4 |
| EXISTING STAIR TREAD SUBSTRATES                                                | 4 |
| ADHESIVE BOND TEST                                                             | 5 |
| <b>INSTALLATION</b>                                                            | 5 |
| DENATURED ALCOHOL                                                              | 5 |
| STRINGERS INSTALLATION                                                         | 5 |
| STAIR NOSING INSTALLATION                                                      | 5 |
| STAIR TREAD & RISER INSTALLATION                                               | 6 |
| HANDLING THE STAIR TREAD NOSE & RISER INTERSECTION                             | 7 |
| FINISHING THE INSTALLATION                                                     | 8 |
| <b>POST INSTALLATION STAIR TREAD PROTECTION</b>                                | 8 |
| <b>SUPPORT &amp; ADDITIONAL RESOURCES</b>                                      | 8 |

### RECOMMENDED ADHESIVES

The adhesives below are the recommended adhesives for installing this product. The first one listed is the primary installation method recommended for applications when the conditions are met as listed. Select the appropriate application method based on the conditions of the substrate. Refer to the adhesive technical data sheet for additional information and when to utilize a different adhesive.

| Required for Installation |                | EN-610 Epoxy Nose Filler is Required for All Vinyl Stair Tread installations. |                               |
|---------------------------|----------------|-------------------------------------------------------------------------------|-------------------------------|
| Adhesive                  | Substrate      | Installation Method                                                           | Recommended Trowel            |
| TP-620                    | All            | Dry-Set                                                                       | Full Coverage of Stairwell    |
| PS-525                    | Absorptive     | Wet-Set                                                                       | 1/16" x 1/16" x 1/16" V Notch |
| PS-525                    | Non-Absorptive | Tacky-Wet                                                                     | 1/16" x 1/32" x 1/32" U Notch |
| U-705                     | Absorptive     | Wet-Set                                                                       | 1/16" x 1/16" x 1/16" V Notch |
| U-705                     | Non-Absorptive | Wet-Set                                                                       | 1/16" x 1/32" x 1/32" U Notch |
| EW-710                    | Absorptive     | Wet-Set                                                                       | 1/16" x 1/16" x 1/16" V Notch |
| EW-710                    | Non-Absorptive | Wet-Set                                                                       | 1/16" x 1/32" x 1/32" U Notch |

We do provide an adhesive bond warranty with our products with these listed adhesives. We do not cover or provide warranty for bond for any adhesives other than the listed recommended adhesives. If another adhesive is utilized, the stated warranty for the product remains in effect but the bond warranty for the adhesive and the stated length of the bond warranty for the adhesive will come from the adhesive manufacturer or distributing agent. However, the use of the recommended adhesives within the installation instructions of the individual products are essential to the specific product performance. We cannot guarantee the same level of performance from an



# Vinyl Stair Tread, Riser, & Stringer

## INSTALLATION

adhesive that is not specifically listed within the technical documents for the specific products, regardless of what the adhesive manufacturer claims.

### INSTALLATION CONSIDERATIONS

***If the profile of the step does not match the profile of the nose of the stair tread and the step cannot be made to conform to the profile of the nose of the stair tread, continuing the installation is not recommended and will not be covered by the product warranty.***

***The Vinyl Stair Tread compound is not designed for use in areas that are exposed to Animal Fats, Vegetable Oils, and/or Petroleum Oils or Lubricants.***

### **ABRASIVE and/or SMOOTH / RIBBED RUBBER INSERTS**

When cutting treads tight to the stringer they will expand slightly due to **thermodynamics** and the **laws of physics**. When this occurs with the treads, the strip will buckle in the channel. Therefore, after installing treads with abrasive or smooth / ribbed rubber inserts, the inserts must be *trimmed 1/16" from the ends on both sides of the tread*.

Stair Treads including abrasive or smooth / ribbed rubber inserts should be treated with extra caution. Folding or carrying longer treads with inserts over the shoulder will cause the inserts to stretch and possibly buckle after installation.

### **BUTTING TREADS and/or PATTERN ALIGNMENT**

***Wider stairwells and stairwells requiring pattern alignment*** will require additional planning and dry fitting prior to installation.

We manufacture our treads according to the requirements of **ASTM F2169** which states "*the length shall be the manufacturer's standard, or as specified, and can be longer to be trimmed to fit*". It is our goal to package treads 1/2" - 3/4" longer than stated to allow for trimming to fit. ***Our treads are intended to be trimmed on each end of the tread length and depth.*** We recommend ordering treads the next size up to achieve these layouts and installations on certain patterned treads.

Determining where the tread will be seamed is up to the designer or end user but typically is in the center or under a handrail to minimize visibility. It is recommended for patterned treads to seam between the patterns if possible and prepare that seam prior to fitting to step for finished length. **ASTM F2169** states "*When butting stair treads together on one stair, there should be no more than 1/16" thickness difference between the two adjoining treads*". It may be necessary once the seam is prepared to place the treads top down on a protected surface and ***sand the back to remove any gauge differential.***

### STORAGE, HANDLING, INSTALLATION, SERVICE, & ACCLIMATION ENVIRONMENT

The reported technical data information for these products is based on a formulation that is designed, manufactured, and evaluated to perform at constant temperatures, not fluctuating more than 10° from normal selected service temperatures from the allowable range.

These products are designed for service within environments ranging from 60° F (15° C) - 85° F (26° C) unless otherwise noted in the specific installation section. These products are designed for service within ambient relative humidity between 40% and 60%.

All products must be stored in an indoor, climate-controlled (60° - 85° F) space and protected from the elements.

All products must be stored on a dry, flat, level surface. Carefully stacked, aligned neatly and not on edge. Do not stack pallets and protect products from damage.

**Service Environment** is defined as the environment in which the materials will be utilized.

**Service temperature** is defined as the normal setting of the HVAC in the environment in which the material is installed, i.e., typically 70° - 72° F in most commercial applications.

**Acclimation of the material** is achieved when the following conditions are met within the installation area.

- The facility or **service environment** must be fully enclosed, sealed and weather tight.
- Building HVAC must be up and running in permanent operation prior to installation (if temporary systems or systems other than the permanent HVAC systems are utilized it must be capable of maintaining the same conditions as the permanent HVAC and/or service conditions).
- Maintain all products and adhesives in the installation area at the **desired service temperatures** for a period of 48 hours prior to installation, during the installation and for the service life of the installation.
- **Temperature** must be maintained between 60° F (15° C) - 85° (26° C), preferably at the **desired service temperature**.



# Vinyl Stair Tread, Riser, & Stringer

## INSTALLATION

- **Relative Humidity** must be maintained between 35% - 65%. Understand that Relative Humidity does not affect the installation of the material, but it can affect the functionality of the adhesives. Outside of the ranges, the stated information regarding open times, flash times, & dry times will vary.

While we understand that most stair treads are installed in areas that are temperature controlled, there are areas where nosings are installed that are not fully temperature controlled. Stair wells that are not commonly used or only used in certain conditions that do not contain ventilation.

- ***In these areas it may be necessary to sand the backs of the nosings for the best performance.***

It is recommended to utilize a cloud-based or similar **data logging system** during installation to provide temperature & humidity data in the event of a warranty issue.

While we do our best to provide quality products and workmanship in our manufacturing facilities, quality installation is the responsibility of the installer. Inspect all material for proper type, color, and matching lot numbers if appropriate. We ask that we are notified of any inaccuracies or defects prior to installation as **we do not pay labor for or material costs on installed materials with visual defects.**

***Users are advised to confirm suitability of these products by their own tests and ensure that all adhesives intended for installation meet the requirements of the end user.***

If there are concerns regarding this information or the service temperature, substrate temperature or installation environment will not meet these requirements, please contact Technical Services for recommendations prior to installation at [solutions@rhctechnical.com](mailto:solutions@rhctechnical.com), we will be happy to discuss and provide direction or confirmation of the project at that time.

### **SUBSTRATE PREPARATION**

All substrates must be clean, smooth, permanently dry, flat, and structurally sound. At the time of installation substrates must be free of visible water or moisture, dust, paint, sweeping compounds, post placement curing compound residues, residual adhesives, chemical adhesive removers, concrete hardeners or densifiers residues, solvents, wax, oil, grease, asphalt, visible alkaline salts or excessive efflorescence, mold, mildew and any other extraneous coating, film, material, or foreign matter. If not, consideration should be taken regarding the effects of these conditions and how they can affect the installation.

It is recommended that all substrates have a **flatness tolerance** of 1/8" in 6' or 3/16" in 10'. Substrates that do not meet this requirement shall have a cementitious patch or self-leveling underlayment installed to flatten the installation area, uneven substrates can and will lead to **wavy noses** after installation.

All substrates must have all existing adhesives, materials, contaminants, or bond-breakers mechanically removed via scraping, sanding, grinding, or buffing with a 25 grit DiamaBrush Prep Plus tool prior to adhesive installation. In extreme situations, shot blasting may be required. Mechanical preparation must expose at least 90% of the original substrate. Following cleaning and removal, all substrates must be vacuumed with a HEPA approved vacuum and flat vacuum attachment to remove all surface dust. Sweeping without vacuuming will not be acceptable.

***Do not use solvent/citrus based or other chemical adhesive removers or oil-based cleaning compounds before installation.***

Regarding substrate preparation when mechanical sanding, grinding, shot blasting, and vacuuming always follow the Resilient Floor Covering Institute's (RFCI) "Recommended Work Practice for Removal of Existing Floor Covering and Adhesives," and all applicable local, state, federal and OSHA requirements regarding Asbestos and Silica containment regulations.

### **NON-APPROVED SUBSTRATES**

**Existing Resilient Stair Tread** products or Concrete substrates that have been abated or prepared with chemical adhesive removers, solvents, or chemical cleaners.

Existing **Checker Plate or Diamond Plate** is not recommended for direct installation. These should be prepared appropriately before installation.

### **CONCRETE SUBSTRATES**

All concrete substrates that have an ICRI Concrete Surface Profile (CSP) over 4 shall be smoothed with a self-leveling underlayment or a patch to prevent imperfections from telegraphing through flooring materials.

All **concrete filled metal pans**, the concrete must be well bonded and secure without movement. It must be flush and level with **rolled metal leading edge** of the step.

- When laying a square or straight edge from back to the front of the step, if the concrete is higher than the leading edge the concrete will need to be ground level and flush.
- If the concrete is lower, then a compatible cementitious patch must be used to level out and make flush.



# Vinyl Stair Tread, Riser, & Stringer

## INSTALLATION

- Make sure that spot welds do not get in the way of the treads along the sides.
- Be sure that concrete is smooth and flat along the sides of the steps where it meets the stringer.

**Moisture testing** is an essential part of determining the suitability of a concrete substrate to receive a resilient stair covering. Moisture testing should be performed on any concrete substrate that shows signs of an issue or where there are concerns present. Typically, moisture testing is not performed on Stair Tread installations. If testing is performed verify results according to the selected adhesive for application for compatibility.

- All concrete substrates must be evaluated per **ASTM F3191** to confirm **porosity (absorption rate)**. This is utilized to determine the method of adhesive application or how the adhesive will act upon the concrete and determine the application method of the adhesive.
- All concrete substrates must be evaluated for **dew point** before installation. The substrate temperature shall be at least 5° F above the dew point.
- All concrete substrates should be evaluated per **ASTM F3441** to determine **pH** range of the concrete at time of installation.

Concrete substrates containing **radiant heating systems** are suitable for this product. Reduce the setting of the system to 65° F for the acclimation period. 48 hours after installation the temperature can be gradually increased to a maximum setting of 85° F.

### WOOD SUBSTRATES

Wood substrates must meet local and national building codes and be prepared appropriately to receive resilient stair treads.

Wood substrates shall be rigid and free of any movement. It shall be structurally sound and designed as a resilient flooring underlayment, smooth enough to prevent telegraphing through the flooring product. At a minimum, existing stripwood plank or any board types that are unacceptable, must be covered with appropriate underlayment grade plywood.

- For stripwood subfloors with a face width of 3" or less and is tongue-and-groove and with a smooth surface, use minimum 1/4" thick approved panel to cover and reduce the potential of board telegraphing.
- For stripwood subfloors with a face width of greater than 3" or not tongue-and-groove, or with a rough surface, use a minimum 1/2" thick approved panel to cover and reduce the potential of board telegraphing.

Countersink nail heads and fill depressions, joints, cracks, gouges, and chipped edges with a good quality Portland cement-based patching compound designed for this purpose.

**Fire & Pressure Treated Plywood** may serve as part of the installation substrate. Many variations of this product are not designed or finished to ensure smoothness necessary underneath resilient flooring and therefore should either be patched, self-leveled, or covered with appropriate underlayment grade plywood prior to the installation of resilient flooring. Consult appropriate manufacturers regarding the types of products and their application over these substrates. If bonding to it directly, our recommendation is to treat the substrate as non-porous or non-absorptive.

**OSB (Oriented Strand Board), particle board, chipboard, lauan, or composite underlayments must not be used directly under resilient stair treads.** These should not be used in Commercial applications and in Residential applications they are not typically smooth enough to allow for the installation of resilient flooring products

### EXISTING STAIR TREAD SUBSTRATES

With **Terrazzo or Ceramic existing stairs**, ensure existing coverings are a single layer of material and that all materials are clean, dry, sound, solid, well adhered, and free of factory and/or site-applied finishes, waxes and/or contaminants. Remove and repair all loose tiles and utilize a suitable primer and cementitious patch to fill grout lines and other depressions.

**Metal substrates** must be mechanically sanded/ground/abraded and cleaned of any residue, oil, rust and/or oxidation. The substrate must be smooth, flat and sound before installation. When installing in areas that may be subject to topical water or moisture and/or high humidity, an anti-corrosive coating must be applied to protect metal substrate. Be sure to follow installation procedures and trowel sizes for non-porous/non-absorptive substrates.

**All resilient flooring materials used as stair tread must be removed to the original substrate prior to the application of new resilient stair tread products.**

### ADHESIVE BOND TEST

An **adhesive bond test** should be performed using actual stair tread and adhesive materials being installed to determine adequacy. Test areas should be a minimum of 36" and remain in place for at least 72 hours prior to evaluation for bond strength to the substrate. This will help to ensure application of the adhesive and the bond achieved is adequate for the project to continue.



# Vinyl Stair Tread, Riser, & Stringer

## INSTALLATION

### INSTALLATION

***By covering a substrate, underlayment, or existing surface, you have indicated acceptance of the substrate and installation environment.***

***All installations of Vinyl Stair Treads require the use of the EN-610 Epoxy Nose Filler.***

***If the profile of the step does not match the profile of the nose of the stair tread and the step cannot be made to conform to the profile of the nose of the stair tread, continuing the installation is not recommended and will not be covered by the product warranty.***

Select the appropriate adhesive for the substrate in which the treads and risers are being installed.

***It is possible for Concrete Filled Metal Pan stairs to require different adhesives or different application methods of the same adhesive for installation.***

### DENATURED ALCOHOL

Denatured alcohol or similar products should be used to clean the back side of the treads prior to installation to ensure a proper bond. In some extreme instances it may be necessary ***to sand the back side of the tread to achieve maximum bond*** prior to wiping with denatured alcohol. Sometimes denatured alcohol is sold as ***camping stove fuel or methyated spirits*** in areas where "denatured alcohol" is not available.

### STRINGERS INSTALLATION

Not all applications will require the use of stringers. If stringers are being installed, they should be installed prior to the installation of the treads and/or risers.

Select the appropriate adhesive for the substrate in which the stringers are being installed. Typically, stringers in new construction are metal and should be treated as ***non-porous*** (non-absorptive) when selecting adhesives. It is acceptable to install stringers with the TP-620 Adhesive.

- Utilize a template when fitting stringers for installation, scribing felt, or similar materials are normally used for this. Use suitable releasable material to hold the template in place while creating the template. When in place, use the appropriate tools to transfer the step profile onto the template.
- Transfer the template to the stringer material and carefully cut the material.
- Check the fit and make any final adjustments before applying the selected adhesive.
- Periodically lift material to ensure proper adhesive coverage. ***Adhesive should cover 90%*** of material when rolled into place.
- Using a suitable hand roller, carefully ***roll material*** to ensure contact with adhesive within 30 minutes of installation.

### STAIR NOSING INSTALLATION

***All stair nosings require the use of the EN-610 Epoxy Nose Filler in the stair nose radius as a filler and as the primary bonding agent of the stair nosing itself on both the horizontal and vertical edges.***

***When using the first mixing nozzle with the EN-610, expel the first 5 - 6 inches coming from the mixer nozzle. When the cartridge is empty, transfer the nozzle to the next cartridge to continue application. This ensures the mixture is appropriate and cures properly. Dispose of the nozzle at the end of the day and use a fresh one starting the next.***

Prior to installing or fitting Stair Nosings, any Stringer material that will be utilized must be installed to ensure the proper installation. Stair nosings which have an ***undercut, underlap or flange*** must be installed prior to the installation of any adjoining flooring and/or riser material.

- Fit stair nosing to step and scribe material for trimming, then carefully trim material along marked line.
- Confirm that stair nosing fits tightly on step, ensuring material is not over-compressed.
- ***Clean the underside of the stair nosing with a clean white rag or towel and denatured alcohol or equivalent.*** Continuously change the rag or towel to prevent transferring mold-release after building up in the cleaning rag or towel. Failure to do so may cause bond issues due to mold-release chemical contamination.

***In areas which may be exposed to excessive moisture, heavy foot traffic, and/or as a platform edge, lightly sand the back of the stair nosing to improve adhesion. After sanding, clean the underside of the stair nosing with denatured alcohol and a clean white rag.***

- Apply a ***1/4" - 1/2"*** bead of the ***EN-610*** to the interior nose of the stair nosing. The amount of material may need to be adjusted. When checking for transfer ensure the bead is being compressed and touching the actual substrate.
- Apply ***EN-610*** to both the horizontal and vertical bonding surfaces of the stair nosing and spread using a 1/8" saw-tooth spreader.



# Vinyl Stair Tread, Riser, & Stringer

## INSTALLATION

- Periodically lift material to ensure proper adhesive coverage. **Adhesive should cover 90%** of nosing when rolled into place.
- Using a suitable hand roller, carefully **roll material** to ensure contact with adhesive within 30 minutes of installation.

***If the stair nosing has an abrasive or smooth / ribbed rubber inserts, the inserts must be trimmed 1/16" from the ends on both sides of the nosing.***

Avoid walking, kneeling, or working on material until adhesive has cured for light foot traffic. To prevent movement and help hold material in place until adhesive is cured the use of a multi-purpose releasable painters' tape is recommended.

### STAIR TREAD & RISER INSTALLATION

#### Handling Extended Width Stairwells

Wider stairwells that require butting two treads together will require additional planning and dry fitting prior to installation. We recommend ordering treads the next size up to achieve these layouts and installations. Treads with VI or Abrasive strips may require mixing and matching to achieve the desired installation result.

Stair treads have an acceptable level of thickness variation from tread to tread. For this reason, stair treads that are intended to be butted together may need to be sanded, undercut, or shimmed to match the thickness of adjacent treads. Treads should be trimmed so that the center of the pattern or profile is at the seam.

Once butting seams are cut and patterns are aligned, **Excelsior U-705 Urethane adhesive** should be used at the seams to help adjust for slight height variations and to hold the seam tight.

#### Handling Top Steps & Mid-Landings

When installing a full-size tread on the top step or landing and it will be butted up to flooring materials on the upper floor or landing, always check the thickness of the two materials. Due to the way treads are manufactured the gauge of the material can vary depending on where they are cut to butt up to the tiles.

***Patching, shimming, or sanding of the treads may be required to match the two materials in thickness for a flush installation. This is especially true on open landings where the tile will have to wrap around the side of the tread.***

#### Three Side Scribe Method for Stair Treads

- When final cutting treads we recommend utilizing an **undercut** to provide for the appearance of a tight fit and leaving room for expansion. There should be no more than a 1/16" gap between the tread and the stringer after installation.
- Determine the center of the stairwell and mark a center line on the riser portion of each step.
- Determine the center of each stair tread and mark a center line on the back edge of the tread for alignment during trimming and installation.
- Align the stair tread to the right side of the step and set the divider to the distance between the center mark on the step riser and the center mark on the stair tread.
- While applying firm pressure to the stringer material with the divider, mark the stair tread with the divider to determine scribe line.
- Use a suitable knife to trim stair tread along scribe mark and create a slight undercut to ease final installation.
- Once the right side of the tread is scribed and trimmed, reposition the stair tread to align to the left side of the step.
- Reset the divider to the distance between the center mark on the step riser and the center mark on the stair tread.
- Use a divider to scribe stair treads as before and trim stair tread along scribe mark, creating a slight undercut.
- Ensure that stair tread fits step snugly against stringers without over-compressing tread material.
- To aid in scribing and trimming the back edge of stair treads, a spacer (such as a carpenter's level, 1" x 2" wood or equivalent) is required to set the depth of the tread.
- Before cutting the back edge of the stair tread, measure the depth of the step and the thickness of the spacer.
- Rough cut stair treads to be at least 1/4" deeper than the step but no deeper than the width of the spacer.
- Once the back edge has been rough cut, align the stair tread to the back of the step riser above.
- Insert the spacer between the leading edge of the stair tread and the step nose. Ensure that the spacer and stair tread fit snugly against the step.
- Set the divider to the exact width of the spacer and scribe the back edge of the stair tread to the step riser.
- Trim the back edge stair tread along scribe mark, creating a slight undercut to ease installation.
- Ensure that all sides of the stair tread fit snugly to step while avoiding over-compressing material.

- Once the initial step has been scribed and trimmed, the riser should be scribed and trimmed to accommodate imperfections in the step stringers using the Two Side Scribe Method.

### Scribing Risers

- Prior to trimming risers, ensure that the stair tread below has been trimmed and fits snugly on the step beneath the riser.
- Use the previous center mark used when trimming the adjoining stair treads as the center of the stairwell, ensuring that center mark is visible while trimming risers.
- Repeat the process for scribing each end of the tread, to scribe both ends of the riser to the stairwell.

### Using the TP-620 Stair Tread Tape

TP-620 is a pressure sensitive stair tread tape adhesive that is amber in color with a visible scrim inside the adhesive with a release paper. It is available in multiple widths for various uses within the installation of stair treads, risers, and/or stringers. It is a firm permanent bond adhesive and not intended to be treated as a releasable adhesive.


- Vacuum the surface with a brush attachment or damp mop the substrate, & allow it to fully dry prior to installation.
- Place the TP-620 roughly 1" from the leading edge of the substrate and cover the width of the tape.
- Roll out the material preventing wrinkles while making sure the tape is smooth and well bonded to the substrate, using a straight edge to smooth the surface will help to prevent wrinkling.
- With the use of the 9.45" tape in this method, it will need to be determined where to place the 1" TP-620 Stair Tread Tape to bond the leading edge of the tread to the substrate. It is recommended to place this inside the nose of the tread after cleaning the tread surface.
- Once TP-620 is in place and Stair Treads are fit properly to the step, installation can proceed.
- Apply the EN-610 to the underside radius of the nose of the stair tread.
- Remove the release paper completely from the tape on the tread portion and a few inches of the tape under the nose, with the nose folded down so that it can be removed once the tread is in place.
- Position the tread, and slowly remove the release paper from the underside of the nose while holding the tread in position on the substrate.

### HANDLING THE STAIR TREAD NOSE & RISER INTERSECTION

The seam between the leading edge (nose) of the stair tread and the riser should be treated using one of the following methods. Regardless of the method utilized, the leading edge (nose) must be fully adhered.


#### Butting or Scribed Seam Method

- When butting stair tread and riser seams using the Scribed Seam Method, ensure that the stair tread above and below the riser, and the riser itself, have been trimmed and fit the step snugly.
- Ensure the stair tread below the riser is in place prior to scribing the riser to ensure a tight fit to the leading edge of the stair tread above.
- Overlap the stair tread above the riser with the riser while ensuring that the riser toe is not over-compressed. Using the leading edge of the stair tread as a guide, a divider or a marking tool is needed to scribe the riser.
- Use a suitable knife to trim the riser along the scribe mark.



#### Overlapping Seam Method

- When overlapping stair tread and riser seams, ensure that the stair tread and riser have been trimmed and fit the step snugly.
- Risers do not normally require trimming on the top edge prior to installation when overlapping seams. However, if the top edge of the riser extends up to or over the height of the step, **trim the riser to 1/4" - 1/2" from the top of the step** to allow space for the **EN-610 Epoxy Nose Filler**.





# Vinyl Stair Tread, Riser, & Stringer

## INSTALLATION

### FINISHING THE INSTALLATION

- When using the Excelsior **TP-620 Pressure Sensitive Tape Adhesive** or the **C-631 Contact Adhesive**, be sure to clean dusty and/or cementitious substrates with a vacuum, sponge, or damp mop prior to installation to remove dust, dirt, and debris.
- **Clean the underside of the stair nosing with a clean white rag or towel and denatured alcohol or equivalent.** Continuously change the rag or towel to prevent transferring mold-release after building up in the cleaning rag or towel. Failure to do so may cause bond issues due to mold-release chemical contamination.
- When installing adhesive on steps, be sure to leave a 1/2" - 3/4" space on either side of the step nose to accommodate the Excelsior EN-610 Epoxy Nose Filler Adhesive, if needed, to avoid adhesive cross-contamination. **When using the first mixing nozzle with the EN-610, expel the first 5 - 6 inches coming from the mixer nozzle. When the cartridge is empty, transfer the nozzle to the next cartridge to continue application. This ensures the mixture is appropriate and cures properly. Dispose of the nozzle at the end of the day and use a fresh one starting the next.**
- **All noses (leading edges) must be adhered to either the riser (if overlapped) or riser substrate (if butted or scribed) when installing stair treads, using either the TP-620 Tread Tape or C-631 Contact Adhesive. This applies to all steps including square edge and ADA steps with an angle.**
- Periodically lift material to ensure proper adhesive coverage. **Adhesive should cover 90%** of nosing when rolled into place.
- Using a suitable hand roller, carefully **roll material** to ensure contact with adhesive within 30 minutes of installation.
- **After installing treads with abrasive or smooth / ribbed rubber inserts, the inserts must be trimmed 1/16" from the ends on both sides of the tread.**

### POST INSTALLATION STAIR TREAD PROTECTION

We recommend that the installation of stair treads be performed after all other trades have completed their work. If this is impossible, properly protecting the new stair treads is essential to prevent damage. So, the following should be considered immediately following the installation process.

Sweep or vacuum stair treads to remove loose dirt, debris, and grit so that it does not become trapped under protection.

Protect newly installed stair treads with construction grade undyed kraft paper or protective boards, such as Ram Board, ThermoPLY, 1/8" Masonite panels, or other materials to prevent damage by other trades.

Restrict traffic for a minimum of 24 hours unless utilizing a dry-set application method (such as TP-620 Tape Adhesive) that allows immediate foot traffic.

Do not allow items to be dragged or slid up or down the stair treads after installation.

Initial Cleaning requirements can take place after a minimum of 72 hours after the installation is completed.

### SUPPORT & ADDITIONAL RESOURCES

|                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|-------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Product Support Phone & Email       | (800) 537 – 9527 / <a href="mailto:sales@roppe.com">sales@roppe.com</a>                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Technical Support Phone & Email     | (844) 393 – 4044 / <a href="mailto:solutions@rhctechical.com">solutions@rhctechical.com</a>                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| Product Technical Documentation     | <a href="http://www.roppe.com">www.roppe.com</a>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| Associated or Related Documentation | <a href="#">Excelsior TP-620 Stair Tread Tape Adhesive</a><br><a href="#">Excelsior EN-610 Epoxy Nose Filler</a><br><a href="#">Excelsior AW-510 Wet-Set Acrylic Adhesive</a><br><a href="#">Excelsior PS-525 Modified Pressure Sensitive Adhesive</a><br><a href="#">Excelsior U-705 Urethane Adhesive</a><br><a href="#">Excelsior EW-710 Urethane Enhanced Two-Part Epoxy Adhesive</a><br><a href="#">Excelsior C-631 Contact Adhesive</a><br><a href="#">Vinyl Stair Tread, Riser, &amp; Stringer Care &amp; Maintenance</a> |

The contents contained within this Installation Sheet may be utilized or copied into another projected related document. While this original document will remain in effect at the time of product installation, this TDS shall not be supplemented or replaced by the resulting project documentation. Any alterations to the wording or requirements contained in or derived from this document shall void all related warranties. Before accepting this document, refer to the product website to confirm that you have the most current revision. These products are intended for installation by professionals. Prior to use the user must determine the suitability of our products for the intended use. The user alone assumes all risks and liability.